
TURN ON FIRST
TURN ON SECOND
Wireless mics × 4
Mic receivers × 2
Audio Mixer 1
XENYX 502S
Bluetooth
Projector
Speakers × 3
Room to Zoom
Zoom to room
Audio Mixer 2
MX400
1/4 in + 3.5 mm
XLR (female)
12 V⎓ INPUT 1 INPUT 2 INPUT 3 INPUT 4 OUTPUT
MicroMIX MX400
4-CHANNEL MIXER
ON LEVEL 1 LEVEL 2 LEVEL 3 LEVEL 4
BLUETOOTH AUDIO
WIRELESS MICS B+C
WIRELESS MICS E+F
WIRED INPUT A
WIRED MIC D
MX400 AUDIO
PROJECTOR AUDIO
SPEAKER X
SPEAKERS Y + Z